

Care Card

- At least once a year, we recommend that you clean and clear the tracks of the roller screen. After the tracks have been cleared and cleaned, liberally lubricate both top and bottom tracks and plastic guides with Mirage Silicone spray lubricant (ask your authorized Mirage Dealer).
- Check and retighten housing mounting screws at top and bottom track screws